

# Колонны ВЭЖХ Hyperpack ODS, Basic

## Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

эл.почта: [taq@nt-rt.ru](mailto:taq@nt-rt.ru) || сайт: <https://teknokroma.nt-rt.ru/>



Due to its characteristics of pore size, surface area, percentage of covering (%C), and the kind of silica it is build of, it is the suitable alternative to Hypersil ODS packings. Its chromatographic behavior exactly reproduces the one of this popular packing, being able to transfer the chromatographic methods without any kind of adjustment.

### 5 Microns Packing

#### Analytical columns 0.46 cm i.d. HYPERPACK

Packing	Funct.	µm	Length		Diameter	Cat.Nbr.
			µm	cm		
Hyperpack	ODS	5	3	0.46	0.46	TR-011000
Hyperpack	ODS	5	4	0.46	0.46	TR-011001
Hyperpack	ODS	5	5	0.46	0.46	TR-011002
Hyperpack	ODS	5	10	0.46	0.46	TR-011003
Hyperpack	ODS	5	15	0.46	0.46	TR-011004
Hyperpack	ODS	5	20	0.46	0.46	TR-011005
Hyperpack	ODS	5	25	0.46	0.46	TR-011006
Hyperpack	C8	5	3	0.46	0.46	TR-011021
Hyperpack	C8	5	4	0.46	0.46	TR-011022
Hyperpack	C8	5	5	0.46	0.46	TR-011023
Hyperpack	C8	5	10	0.46	0.46	TR-011024
Hyperpack	C8	5	15	0.46	0.46	TR-011025
Hyperpack	C8	5	20	0.46	0.46	TR-011026
Hyperpack	C8	5	25	0.46	0.46	TR-011027

### 5 Microns Packing

#### Analytical columns 0.4 cm i.d. HYPERPACK

Packing	Funct.	µm	Length		Diameter	Cat.Nbr.
			µm	cm		
Hyperpack	ODS	5	3	0.4	0.4	TR-411000
Hyperpack	ODS	5	4	0.4	0.4	TR-411001
Hyperpack	ODS	5	5	0.4	0.4	TR-411002
Hyperpack	ODS	5	10	0.4	0.4	TR-411003
Hyperpack	ODS	5	15	0.4	0.4	TR-411004
Hyperpack	ODS	5	20	0.4	0.4	TR-411005
Hyperpack	ODS	5	25	0.4	0.4	TR-411006
Hyperpack	C8	5	3	0.4	0.4	TR-410081
Hyperpack	C8	5	4	0.4	0.4	TR-410082
Hyperpack	C8	5	5	0.4	0.4	TR-410083
Hyperpack	C8	5	10	0.4	0.4	TR-410084
Hyperpack	C8	5	15	0.4	0.4	TR-410085
Hyperpack	C8	5	20	0.4	0.4	TR-410086
Hyperpack	C8	5	25	0.4	0.4	TR-410087

### 5 Microns Packing

#### Microbore columns 0.21 cm i.d. HYPERPACK

Packing	Funct.	µm	Length		Diameter	Cat.Nbr.
			µm	cm		
Hyperpack	ODS	5	3	0.21	0.21	TR-010272
Hyperpack	ODS	5	5	0.21	0.21	TR-010273
Hyperpack	ODS	5	10	0.21	0.21	TR-010274
Hyperpack	ODS	5	15	0.21	0.21	TR-010275
Hyperpack	ODS	5	20	0.21	0.21	TR-010276
Hyperpack	ODS	5	25	0.21	0.21	TR-010277
Hyperpack	C8	5	3	0.21	0.21	TR-011028
Hyperpack	C8	5	5	0.21	0.21	TR-011029
Hyperpack	C8	5	10	0.21	0.21	TR-011030
Hyperpack	C8	5	15	0.21	0.21	TR-011031
Hyperpack	C8	5	20	0.21	0.21	TR-011032
Hyperpack	C8	5	25	0.21	0.21	TR-011033

### 5 Microns Packing

#### Microbore columns 0.3 cm i.d. HYPERPACK

Packing	Funct.	µm	Length		Diameter	Cat.Nbr.
			µm	cm		
Hyperpack	ODS	5	3	0.3	0.3	TR-010278
Hyperpack	ODS	5	5	0.3	0.3	TR-010279
Hyperpack	ODS	5	10	0.3	0.3	TR-010280
Hyperpack	ODS	5	15	0.3	0.3	TR-010281
Hyperpack	ODS	5	20	0.3	0.3	TR-010282
Hyperpack	ODS	5	25	0.3	0.3	TR-010283
Hyperpack	C8	5	3	0.3	0.3	TR-011160
Hyperpack	C8	5	5	0.3	0.3	TR-011034
Hyperpack	C8	5	10	0.3	0.3	TR-011035
Hyperpack	C8	5	15	0.3	0.3	TR-011036
Hyperpack	C8	5	20	0.3	0.3	TR-011037
Hyperpack	C8	5	25	0.3	0.3	TR-011038

### 5 Microns Packing

#### Semi-preparative columns HYPERPACK

Packing	Funct.	µm	Length		Diameter	Cat.Nbr.
			µm	cm		
Hyperpack	ODS	5	10	0.78	0.78	TR-010284
Hyperpack	ODS	5	15	0.78	0.78	TR-010285
Hyperpack	ODS	5	25	0.78	0.78	TR-010286
Hyperpack	ODS	5	10	1.00	1.00	TR-010287
Hyperpack	ODS	5	15	1.00	1.00	TR-010288



Packing	Funct.	µm	Length Diameter		Cat.Nbr.
			cm	cm	
Hyperpack	ODS	5	25	1.00	TR-010289
Hyperpack	ODS	5	5	2.12	TR-010290
Hyperpack	ODS	5	10	2.12	TR-010291
Hyperpack	ODS	5	15	2.12	TR-010292
Hyperpack	ODS	5	25	2.12	TR-010293
Hyperpack	C8	5	10	0.78	TR-011039
Hyperpack	C8	5	15	0.78	TR-011040
Hyperpack	C8	5	25	0.78	TR-011041
Hyperpack	C8	5	10	1.00	TR-011042
Hyperpack	C8	5	15	1.00	TR-011043
Hyperpack	C8	5	25	1.00	TR-011044
Hyperpack	C8	5	5	2.12	TR-011045
Hyperpack	C8	5	10	2.12	TR-011046
Hyperpack	C8	5	15	2.12	TR-011047
Hyperpack	C8	5	25	2.12	TR-011048

### 3 Microns Packing

Ultraprapid columns 0.46 cm i.d. HYPERPACK

Packing	Funct.	µm	Length Diameter		Cat.Nbr.
			cm	cm	
Hyperpack	ODS	3	3	0.46	TR-010298
Hyperpack	ODS	3	4	0.46	TR-010299
Hyperpack	ODS	3	5	0.46	TR-010300
Hyperpack	ODS	3	10	0.46	TR-010301
Hyperpack	ODS	3	15	0.46	TR-010302
Hyperpack	ODS	3	20	0.46	TR-010303
Hyperpack	ODS	3	25	0.46	TR-010304
Hyperpack	C8	3	3	0.46	TR-011053
Hyperpack	C8	3	4	0.46	TR-011054
Hyperpack	C8	3	5	0.46	TR-011055
Hyperpack	C8	3	10	0.46	TR-011056
Hyperpack	C8	3	15	0.46	TR-011057
Hyperpack	C8	3	20	0.46	TR-011058
Hyperpack	C8	3	25	0.46	TR-011059

### 3 Microns Packing

Analytical columns 0.4 cm i.d. HYPERPACK

Packing	Funct.	µm	Length Diameter		Cat.Nbr.
			cm	cm	
Hyperpack	ODS	3	3	0.4	TR-410298
Hyperpack	ODS	3	4	0.4	TR-410299
Hyperpack	ODS	3	5	0.4	TR-410300
Hyperpack	ODS	3	10	0.4	TR-410301
Hyperpack	ODS	3	15	0.4	TR-410302
Hyperpack	ODS	3	20	0.4	TR-410303
Hyperpack	ODS	3	25	0.4	TR-410304
Hyperpack	C8	3	4	0.4	TR-011060
Hyperpack	C8	3	5	0.4	TR-011061
Hyperpack	C8	3	10	0.4	TR-011062
Hyperpack	C8	3	15	0.4	TR-011063

Hyperpack	C8	3	20	0.4	TR-011064
Hyperpack	C8	3	25	0.4	TR-011065

### 3 Microns Packing

Microbore columns 0.21 cm i.d. HYPERPACK

Packing	Funct.	µm	Length Diameter		Cat.Nbr.
			cm	cm	
Hyperpack	ODS	3	3	0.21	TR-010305
Hyperpack	ODS	3	5	0.21	TR-010306
Hyperpack	ODS	3	10	0.21	TR-010307
Hyperpack	ODS	3	15	0.21	TR-010308
Hyperpack	ODS	3	20	0.21	TR-010309
Hyperpack	ODS	3	25	0.21	TR-010310
Hyperpack	C8	3	3	0.21	TR-011066
Hyperpack	C8	3	5	0.21	TR-011067
Hyperpack	C8	3	10	0.21	TR-011068
Hyperpack	C8	3	15	0.21	TR-011069
Hyperpack	C8	3	20	0.21	TR-011070
Hyperpack	C8	3	25	0.21	TR-011071

### 3 Microns Packing

Microbore columns 0.3 cm i.d. HYPERPACK

Packing	Funct.	µm	Length Diameter		Cat.Nbr.
			cm	cm	
Hyperpack	ODS	3	3	0.3	TR-010311
Hyperpack	ODS	3	5	0.3	TR-010312
Hyperpack	ODS	3	10	0.3	TR-010313
Hyperpack	ODS	3	15	0.3	TR-010314
Hyperpack	ODS	3	20	0.3	TR-010315
Hyperpack	ODS	3	25	0.3	TR-010316
Hyperpack	ODS	3	3	0.3	TR-011072
Hyperpack	ODS	3	5	0.3	TR-011073
Hyperpack	ODS	3	10	0.3	TR-011074
Hyperpack	ODS	3	15	0.3	TR-011075
Hyperpack	ODS	3	20	0.3	TR-011076
Hyperpack	ODS	3	25	0.3	TR-011077



It reproduces with total fidelity the chromatographic behavior of the columns Hypersil BDS C18. Available in 3 and 5µm and in all length and diameter configurations.

### 5 Microns Packing

#### Analytical columns 0.46 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	5	3	0.46	TR-011007
Hyperpack BASIC	ODS	5	4	0.46	TR-011008
Hyperpack BASIC	ODS	5	5	0.46	TR-011009
Hyperpack BASIC	ODS	5	10	0.46	TR-011010
Hyperpack BASIC	ODS	5	15	0.46	TR-011011
Hyperpack BASIC	ODS	5	20	0.46	TR-011012
Hyperpack BASIC	ODS	5	25	0.46	TR-011013
Hyperpack BASIC	C8	5	3	0.46	TR-011108
Hyperpack BASIC	C8	5	4	0.46	TR-011109
Hyperpack BASIC	C8	5	5	0.46	TR-011110
Hyperpack BASIC	C8	5	10	0.46	TR-011111
Hyperpack BASIC	C8	5	15	0.46	TR-011112
Hyperpack BASIC	C8	5	20	0.46	TR-011113
Hyperpack BASIC	C8	5	25	0.46	TR-011114

### 5 Microns Packing

#### Analytical columns 0.4 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	5	3	0.4	TR-411007
Hyperpack BASIC	ODS	5	4	0.4	TR-411008
Hyperpack BASIC	ODS	5	5	0.4	TR-411009
Hyperpack BASIC	ODS	5	10	0.4	TR-411010
Hyperpack BASIC	ODS	5	15	0.4	TR-411011
Hyperpack BASIC	ODS	5	20	0.4	TR-411012
Hyperpack BASIC	ODS	5	25	0.4	TR-411013

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	C8	5	3	0.4	TR-411108
Hyperpack BASIC	C8	5	4	0.4	TR-411109
Hyperpack BASIC	C8	5	5	0.4	TR-411110
Hyperpack BASIC	C8	5	10	0.4	TR-411111
Hyperpack BASIC	C8	5	15	0.4	TR-411112
Hyperpack BASIC	C8	5	20	0.4	TR-411113
Hyperpack BASIC	C8	5	25	0.4	TR-411114

### 5 Microns Packing

#### Microbore columns 0.21 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	5	3	0.21	TR-010317
Hyperpack BASIC	ODS	5	5	0.21	TR-010318
Hyperpack BASIC	ODS	5	10	0.21	TR-010319
Hyperpack BASIC	ODS	5	15	0.21	TR-010320
Hyperpack BASIC	ODS	5	20	0.21	TR-010321
Hyperpack BASIC	ODS	5	25	0.21	TR-010322
Hyperpack BASIC	C8	5	3	0.21	TR-011115
Hyperpack BASIC	C8	5	5	0.21	TR-011116
Hyperpack BASIC	C8	5	10	0.21	TR-011117
Hyperpack BASIC	C8	5	15	0.21	TR-011118
Hyperpack BASIC	C8	5	20	0.21	TR-011119
Hyperpack BASIC	C8	5	25	0.21	TR-011120

### 5 Microns Packing

#### Microbore columns 0.3 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	5	3	0.3	TR-010323
Hyperpack BASIC	ODS	5	5	0.3	TR-010324
Hyperpack BASIC	ODS	5	10	0.3	TR-010325
Hyperpack BASIC	ODS	5	15	0.3	TR-010326
Hyperpack BASIC	ODS	5	20	0.3	TR-010327
Hyperpack BASIC	ODS	5	25	0.3	TR-010328
Hyperpack BASIC	C8	5	3	0.3	TR-011121
Hyperpack BASIC	C8	5	5	0.3	TR-011122
Hyperpack BASIC	C8	5	10	0.3	TR-011123
Hyperpack BASIC	C8	5	15	0.3	TR-011124
Hyperpack BASIC	C8	5	20	0.3	TR-011125
Hyperpack BASIC	C8	5	25	0.3	TR-011126

### 5 Microns Packing

#### Semi Preparative columns HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	5	10	0.78	TR-010329
Hyperpack BASIC	ODS	5	15	0.78	TR-010330
Hyperpack BASIC	ODS	5	25	0.78	TR-010331
Hyperpack BASIC	ODS	5	10	1.00	TR-010332



Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	5	15	1.00	TR-010333
Hyperpack BASIC	ODS	5	25	1.00	TR-010334
Hyperpack BASIC	ODS	5	5	2.12	TR-010335
Hyperpack BASIC	ODS	5	10	2.12	TR-010336
Hyperpack BASIC	ODS	5	15	2.12	TR-010337
Hyperpack BASIC	ODS	5	25	2.12	TR-010338
Hyperpack BASIC	C8	5	10	0.78	TR-011127
Hyperpack BASIC	C8	5	15	0.78	TR-011128
Hyperpack BASIC	C8	5	25	0.78	TR-011129
Hyperpack BASIC	C8	5	10	1.00	TR-011130
Hyperpack BASIC	C8	5	15	1.00	TR-011131
Hyperpack BASIC	C8	5	25	1.00	TR-011132
Hyperpack BASIC	C8	5	5	2.12	TR-011133
Hyperpack BASIC	C8	5	10	2.12	TR-011134
Hyperpack BASIC	C8	5	15	2.12	TR-011135
Hyperpack BASIC	C8	5	25	2.12	TR-011136

### 5 Microns Packing Cartridge System 0.4 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	5	7,5	0.4	TR-010339
Hyperpack BASIC	ODS	5	10	0.4	TR-010340
Hyperpack BASIC	ODS	5	15	0.4	TR-010341
Hyperpack BASIC	ODS	5	25	0.4	TR-010342
Hyperpack BASIC	C8	5	7,5	0.4	TR-011137
Hyperpack BASIC	C8	5	10	0.4	TR-011138
Hyperpack BASIC	C8	5	15	0.4	TR-011139
Hyperpack BASIC	C8	5	25	0.4	TR-011140

### 3 Microns Packing Analytical Columns 0.46 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	3	3	0.46	TR-011014
Hyperpack BASIC	ODS	3	4	0.46	TR-011015
Hyperpack BASIC	ODS	3	5	0.46	TR-011016
Hyperpack BASIC	ODS	3	10	0.46	TR-011017
Hyperpack BASIC	ODS	3	15	0.46	TR-011018
Hyperpack BASIC	ODS	3	20	0.46	TR-011019
Hyperpack BASIC	ODS	3	25	0.46	TR-011020
Hyperpack BASIC	C8	3	3	0.46	TR-011141
Hyperpack BASIC	C8	3	4	0.46	TR-011142
Hyperpack BASIC	C8	3	5	0.46	TR-011143
Hyperpack BASIC	C8	3	10	0.46	TR-011144
Hyperpack BASIC	C8	3	15	0.46	TR-011145
Hyperpack BASIC	C8	3	20	0.46	TR-011146
Hyperpack BASIC	C8	3	25	0.46	TR-011147

### 3 Microns Packing Ultrarapid Columns 0.4 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	3	3	0.4	TR-411014
Hyperpack BASIC	ODS	3	4	0.4	TR-411015
Hyperpack BASIC	ODS	3	5	0.4	TR-411016
Hyperpack BASIC	ODS	3	10	0.4	TR-411017
Hyperpack BASIC	ODS	3	15	0.4	TR-411018
Hyperpack BASIC	ODS	3	20	0.4	TR-411019
Hyperpack BASIC	ODS	3	25	0.4	TR-411020
Hyperpack BASIC	C8	3	3	0.4	TR-411141
Hyperpack BASIC	C8	3	4	0.4	TR-411142
Hyperpack BASIC	C8	3	5	0.4	TR-411143
Hyperpack BASIC	C8	3	10	0.4	TR-411144
Hyperpack BASIC	C8	3	15	0.4	TR-411145
Hyperpack BASIC	C8	3	20	0.4	TR-411146
Hyperpack BASIC	C8	3	25	0.4	TR-411147

### 3 Microns Packing Microbore Columns 0.21 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	3	3	0.21	TR-010343
Hyperpack BASIC	ODS	3	5	0.21	TR-010344
Hyperpack BASIC	ODS	3	10	0.21	TR-010345
Hyperpack BASIC	ODS	3	15	0.21	TR-010346
Hyperpack BASIC	ODS	3	20	0.21	TR-010347
Hyperpack BASIC	ODS	3	25	0.21	TR-010348
Hyperpack BASIC	C8	3	3	0.21	TR-011148
Hyperpack BASIC	C8	3	5	0.21	TR-011149
Hyperpack BASIC	C8	3	10	0.21	TR-011150
Hyperpack BASIC	C8	3	15	0.21	TR-011151
Hyperpack BASIC	C8	3	20	0.21	TR-011152
Hyperpack BASIC	C8	3	25	0.21	TR-011153

### 3 Microns Packing Microbore Columns 0.3 cm i.d. HYPERPACK BASIC

Packing	Funct.	Length		Diameter	Cat.Nbr.
		µm	cm	cm	
Hyperpack BASIC	ODS	3	3	0.3	TR-010349
Hyperpack BASIC	ODS	3	5	0.3	TR-010350
Hyperpack BASIC	ODS	3	10	0.3	TR-010351
Hyperpack BASIC	ODS	3	15	0.3	TR-010352
Hyperpack BASIC	ODS	3	20	0.3	TR-010353
Hyperpack BASIC	ODS	3	25	0.3	TR-010354
Hyperpack BASIC	C8	3	3	0.3	TR-011154
Hyperpack BASIC	C8	3	5	0.3	TR-011155
Hyperpack BASIC	C8	3	10	0.3	TR-011156
Hyperpack BASIC	C8	3	15	0.3	TR-011157
Hyperpack BASIC	C8	3	20	0.3	TR-011158
Hyperpack BASIC	C8	3	25	0.3	TR-011159

## По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

эл.почта: [taq@nt-rt.ru](mailto:taq@nt-rt.ru) || сайт: <https://teknokroma.nt-rt.ru/>